How to import or export configurations

1. Access the device settings menu via Ethernet.
   (1) Configure your PC's IP setting to static and then set the IP address to any address from 192.168.19.2 to 192.168.19.250
   (2) Connect your PC's network port to the device WAN port.
   (3) Enter the IP address 192.168.19.1 in your browser.
   (4) In the PRISM login screen use the following login:
   Username: prism
   Password: prism



   Note:
   1. If the device IP address and username/password have been changed, please use the new IP address and username/password to login.
   2. You can refer to the Quick Start Guide for more information on how to login device.

2. After logging into the web GUI, click on the gear icon located at the top right of the page to reveal additional firmware actions.



3. Click on “Backup Configurations” and click on “Download file” to start to backup the device configurations. It will save as a “tar” format file.



4. Click on “Backup Configurations” and click on “Upload file” and select the backup file(xxx.tar) to start to restore the device configurations with the backup file.