How to setup Multi-WAN for MO10 And MI10

WAN (Wide Area Network) is used to connect with other networks, such as the Internet. It forwards data from the internal LAN devices. You can follow the steps below to set up multi-WAN for MI10 and MO10.

1. Access the device settings menu via Ethernet.
   (1) Configure your PC's IP setting to static and then set the IP address to any address from 192.168.19.2 to 192.168.19.250
   (2) Connect your PC's network port to the device WAN port.
   (3) Enter the IP address 192.168.19.1 in your browser.
   (4) In the PRISM login screen use the following login:
   Username: prism
   Password: prism



Note:
1. If the device IP address and username/password have been changed, please use the new IP address and username/password to login.
2. You can refer to the Quick Start Guide for more information on how to login device.

2. Go to Settings/Network/Zones page to add new network and set the Network type as WAN.



3. Fill in the required IP settings information for the new network zone.
4. Navigate to Settings/Network/Ethernet page and assign Ethernet 0 (LAN2) as the newly added network zone (referred to as Internet 1)



5. If needed, you can also set Ethernet 1 (LAN1) as another WAN network zone.
6. When Ethernet 2 (WAN) is disconnected (the default route metric is 0), it will automatically switch to the new WAN network zone (Internet 1) until Ethernet 2 (WAN) comes back online.