How to change wireless SSID or security type settings

SSID stands for "Service Set Identifier." It is a unique name that identifies a wireless network. When you want to connect a device, such as a laptop or smartphone, to a Wi-Fi network, you will see a list of available networks, each with its own SSID. It allows devices to distinguish one network from another, even when multiple networks are available in the same area. You can follow the steps below to set up wireless SSID or security type for MI10 and MO10.

1. Access the device settings menu via Ethernet.
   (1) Configure your PC's IP setting to static and then set the IP address to any address from 192.168.19.2 to 192.168.19.250
   (2) Connect your PC's network port to the device WAN port.
   (3) Enter the IP address 192.168.19.1 in your browser.
   (4) In the PRISM login screen use the following login:
   Username: prism
   Password: prism



   Note:
   A. If the device IP address and username/password have been changed, please use the new IP address and username/password to login.
   B. You can refer to the Quick Start Guide for more information on how to login device.

2. After logging in to the device's web GUI, navigate to the Settings/Wireless/ Networks to show the wireless VAP settings page.
3. You can modify the SSID to your desired name, select the security type, enter the passphrase, and determine which radios you want to enable for the SSID.



Note:

A. It supports wireless security types Open/WPA2 PSK/WPA2 Enterprise/WPA3 PSK/ WPA3 Enterprise for MI10 and MO10

B. You can enable the SSID with 2.4GHz radio and 5GHz radio(5G-1/5G-2) alone or simultaneously, with a maximum of triple band radios using the same SSID.

C. If you don't want to broadcast the SSID in the network environment, you can enable the "Hide SSID" feature.