How to enable or disable the SSH service

SSH, which stands for Secure Shell, is a cryptographic network protocol used to secure data communication over a computer network. It's widely used for secure remote administration of servers and other network devices. You can follow the steps below to enable SSH service for MI10 and MO10.

1. Access the device settings menu via Ethernet.
   (1) Configure your PC's IP setting to static and then set the IP address to any address from 192.168.19.2 to 192.168.19.250
   (2) Connect your PC's network port to the device WAN port.
   (3) Enter the IP address 192.168.19.1 in your browser.
   (4) In the PRISM login screen use the following login:
   Username: prism
   Password: prism



Note:
1. If the device IP address and username/password have been changed, please use the new IP address and username/password to login.
2. You can refer to the Quick Start Guide for more information on how to login device.

2. After logging in to the device's web GUI, navigate to the Settings/Service/SSH to show the SSH settings page.



3. You can enable the SSH service with specific port (default is enabled with port 22) or disable the SSH service to not allow remote SSH access.