How to use Traceroute to check the network with the AP

Traceroute is a network diagnostic tool used to trace the route that packets take across a network. It provides information about the path that data packets follow from the source to the destination. You can follow the steps below to run Traceroute command for MI10 and MO10.

1. Access the device settings menu via Ethernet.
   (1) Configure your PC's IP setting to static and then set the IP address to any address from 192.168.19.2 to 192.168.19.250
   (2) Connect your PC's network port to the device WAN port.
   (3) Enter the IP address 192.168.19.1 in your browser.
   (4) In the PRISM login screen use the following login:
   Username: prism
   Password: prism



Note:
1. If the device IP address and username/password have been changed, please use the new IP address and username/password to login.
2. You can refer to the Quick Start Guide for more information on how to login device.

2. After logging in to the device's web GUI, navigate to the Tools/Traceroute to show the Traceroute tool page.



3. According to your environment, you can select to use IPv6 or IPv4 to run the Traceroute command.
4. Input the IP address or the host name that you want to check and then press “Traceroute” to run the Traceroute command.